



SPARE PART LIST

**REMOTE CONTROL FOR
SKANDIA DISTRIBUTORS**



DISTRIBUTORS REMOTE CONTROL

CHAIN ELEVATOR




CHAIN & FLIGHT ELEVATOR 25 T/H

| <u>Fig</u> | <u>Part no</u> | <u>Description</u> |
|------------|----------------|-----------------------------|
| 1 | FJ0545 | Connecting pipe 25x2x150 |
| 2 | FJ0530 | Universal joint |
| 3 | 616075 | Pipe 3.0 mtr |
| 4 | FJ0630 | Support plate c/w U-form |
| 5 | FJ0220 | U-form with recess |
| 6 | ÖGÄST8195 | Threaded rod M8x195 |
| 7 | FJ0540 | Connecting pipe 20x2x150 |
| 8 | FJ0645 | Support plate |
| 9 | SSBT1220 | Stop screw M12x20 |
| 10 | PKUL10 | Knob för handle |
| 11 | FJ0550 | Remote control handle |
| 12 | FJ0570 | Outlet indicator c/w U-form |

CHAIN & FLIGHT ELEVATOR 40 T/H

| <u>Fig</u> | <u>Part no</u> | <u>Description</u> |
|------------|----------------|-----------------------------|
| 1 | FJ0545 | Connecting pipe 25x2x150 |
| 2 | FJ0530 | Universal joint |
| 3 | 616075 | Pipe 3.0 mtr |
| 4 | FJ0630 | Support plate c/w U-form |
| 5 | FJ0220 | U-form with recess |
| 6 | ÖGÄST8260 | Threaded rod M8x260 |
| 7 | FJ0540 | Connecting pipe 20x2x150 |
| 8 | FJ0645 | Support plate |
| 9 | SSBT1220 | Stop screw M12x20 |
| 10 | PKUL10 | Knob for handle |
| 11 | FJ0550 | Remote control handle |
| 12 | FJ0570 | Outlet indicator c/w U-form |

**DISTRIBUTORS REMOTE CONTROL
BUCKET ELEVATOR**



BUCKET ELEVATOR TYPE 140

| <u>Fig</u> | <u>Part no</u> | <u>Description</u> |
|------------|----------------|----------------------------|
| 1 | FJ0545 | Connecting pipe 25x2x150 |
| 2 | FJ0530 | Universal joint |
| 3 | 616075 | Pipe 3.0 mtr |
| 4 | FJ0650 | Support plate c/w strap |
| 5 | EF0411 | Strengthening plate |
| 6 | EF0470 | Lock iron |
| 7 | FJ0540 | Connecting pipe 20x2x150 |
| 8 | FJ0665 | Support plate |
| 9 | SSBT1220 | Stop screw M12x20 |
| 10 | PKUL10 | Knob for handle |
| 11 | FJ0550 | Remote control handle |
| 12 | FJ0595 | Outlet indicator c/w strap |

BUCKET ELEVATOR TYPE 200

| <u>Fig</u> | <u>Part no</u> | <u>Description</u> |
|------------|----------------|----------------------------|
| 1 | FJ0545 | Connecting pipe 25x2x150 |
| 2 | FJ0530 | Universal joint |
| 3 | 616075 | Pipe 3.0 mtr |
| 4 | FJ0670 | Support plate c/w strap |
| 5 | EF1411 | Strengthening plate |
| 6 | EF1470 | Lock iron |
| 7 | FJ0540 | Connecting pipe 20x2x150 |
| 8 | FJ0665 | Support plate |
| 9 | SSBT1220 | Stop screw M12x20 |
| 10 | PKUL10 | Knob for handle |
| 11 | FJ0550 | Remote control handle |
| 12 | FJ0610 | Outlet indicator c/w strap |